

ASSEMBLY INSTRUCTION


FORMA TV STAND H70 : 165 x 45 x 70 cm



LS SKU # 110500

CAUTION: PLEASE READ ALL INSTRUCTIONS BEFORE STARTING THE ASSEMBLY OF THIS PRODUCT. THESE PIECES ARE HEAVY. IN ORDER TO PREVENT PERSONAL INJURY AND ENSURE THAT THIS PRODUCT IS NOT DAMAGED DURING THE ASSEMBLY PROCESS, IT IS STRONGLY RECOMMENDED THAT YOU ENLIST THE ASSISTANCE OF ONE OR MORE PEOPLE.

ATTENTION: VEUILLEZ LIRE, TOUTES LES INSTRUCTIONS AVANT DE COMMENCER L'ASSEMBLAGE DE CE PRODUIT. LES PIECES SONT LOURDES. POUR EVITER TOUTE BLESSURE ET POUR VOUS ASSURER QUE LE PRODUIT N'EST PAS ENDOMMAGE' PENDANT L'ASSEMBLAGE, NOUS VOUS RECOMMANDONS DE FAIRE APPEL A UNE OU PLUSIEURS AUTRES PERSONNES.

CUIDADO: FAVOR DE LEER TODAS LAS INSTRUCCIONES ANTES DE ENSAMBLAR SU PRODUCTO, ESTAS PIEZAS SON PESADAS. PARA PREVENIR HERIDAS PERSONALES Y ASEGURAR QUE SU PRODUCTO NO SEA DANADO MIENTRAS ES ENSAMBLADO, SE RECOMIENDA LA ASISTENCIA DE UNA O MAS PERSONAS



LIST OF PARTS AND HARDWARE			
No	Description		Q'ty
A		TV STAND H70	1
B		METAL LEG	2

LIST OF PARTS AND HARDWARE				
No	Description			Q'ty
1		Washer	Ø8xØ18	12
2		Bolt	M6x20	12
3		Allen key	4mm	1
4		Bracket		4
5		Tie		2
6		Screw	M4x20	4
7		Screw	M4x35	4



LIVING SPACES

ASSEMBLY INSTRUCTION

FORMA TV STAND H70 : 165 x 45 x 70 cm

LS SKU # 110500

