



# DENA ACCENT CHAIR

256080/256081







Assembly instructions:

## PARTS LIST

SKU#	DESCRIPTION	IMAGE	QTY
5200	Left Frame		1
5300	Right Frame		1
5400	Seat Cushion		1
5500	Back Frame		1
5600	Back Cushion		1

## HARDWARE LIST

SKU#	DESCRIPTION	IMAGE	QTY
5210	Bolt Ø1/4"×1-1/2"		12
5220	Spring Washer Ø1/4"×10mm		12
5230	Flat Washer Ø1/4"×19mm		7
5240	Flat Washer Ø1/4"×12mm		5
7777	Allen Wrench		1
5250	Wood Plug		5



### PARTS LIST

SKU#	DESCRIPTION	IMAGE	QTY
5200	Left Frame		1
5300	Right Frame		1
5400	Seat Cushion		1
5500	Back Frame		1
5600	Back Cushion		1

### HARDWARE LIST

SKU#	DESCRIPTION	IMAGE	QTY
5210	Bolt Ø1/4"*1-1/2"		12
5220	Spring Washer Ø1/4"*10mm		12
5230	Flat Washer Ø1/4"*19mm		7
5240	Flat Washer Ø1/4"*12mm		5
7777	Allen Wrench		1
5250	Wood Plug		5

