


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

5910 Sofa Table

REVISION 0 : 05/11/2004 REVISION 1 : 09/26/2011 REVISION 2 : 12/16/2011 REVISION 3 : 08/13/2018 REVISION 4 : 11/14/2019 REVISION 5 : 06/03/2022

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM:5910

COASTER

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

Α	LEG FRAME	2PCS
В	SHELF	2SETS
С	APRON	2PCS
D	TOP PANEL	1PC


HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 - BLK)		1PC
2	LONG BOLT (M6 x 60mm - RBW)		4PCS
3	WOOD PLUG (13MM)		4PCS
4	SHORT BOLT (M6 x 35mm - BLK)		8PCS
5	LOCK WASHER (M6 - RBW)		8PCS
6	FLAT WASHER (M6 - RBW)		8PCS
7	BARREL NUT (M6 - SR)		4PCS
8	FLAT HEAD SCREW (M4 x 25mm - RBW)	() 	6PCS


ITEM:**5910**




ASSEMBLY INSTRUCTIONS STEP 1



STEP 2



STEP 3 COMPLETE




COASTERFURNITURE.COM

PAGE 3 OF 3

ITEM:**5910**





Note: Dimension tolerance ±5%