


ASSEMBLY INSTRUCTIONS.

02 TV CABINET BROWN

BZ-1020-24



THANK YOU FOR YOUR PURCHASE!

PARTS & HARDWARE.

PART LIST

NO	DESCRIPTION	IMAGE	Qty
A.	TV CABINET		1
В.	LEG	<u> </u>	2

HARDWARE LIST


C.	Allen Bolt 6 x 40mm	6
D.	Flat Washer 8 x 25mm	6
E.	Spring Washer Ø8mm	6
F.	Allen Key 4mm	1

NOTES.


Thank you for purchasing this quality product! Be sure to check all packing material carefully for small part that May have come loose inside the carton during shipping.

CAUTION: The Item is heavy, assembly should be performed by two people.










STEP 3.



STEP 4.

